

VINYL APPLICATION GUIDELINES:



PREPARE SURFACE, REMOVE ANY
DIRT / GRIME ETC WITH A CLEAN
LINT FREE CLOTH.



USING THE TAPE PROVIDED PIN ON
YOUR TEXT / LOGO INTO PLACE
SO YOU CAN THEN MEASURE IT.



MEASURE FROM A CREASE LINE OR
BOTTOM OF A DOOR, (ANY STRAIGHT
LINE) TO THE BASE LINE WE
HAVE HELPFULLY DRAWN TO GET
THE ITEM STRAIGHT



RUN TAPE ALONG THE TOP OR
BOTTOM EDGE TO CREATE A 'HINGE'.



CUT INTO MANAGEABLE SECTIONS
BETWEEN THE TEXT.



FLIP OVER AND REMOVE THE BACKING SHEET TO LEAVE YOU WITH JUST THE VINYL AND CARRIER TAPE



APPLY FIRM EVEN PRESSURE WITH THE SUPPLIED SQUEEGIE ENSURING THAT ALL THE TAPE AND VINYL IS RUBBED DOWN WELL REPEAT UNTIL ALL YOUR VINYL IS APPLIED



REMOVE ALL THE CARRIER TAPE USING THE TECHNIQUE SHOWN LEFT



USING THE KNIFE PROVIDED PIERCE ANY AIR BUBBLES YOU MAY HAVE CREATED WHEN APPLYING THE VINYL



FINALLY, FOR DOOR SHUTS ETC SIMPLY TRIM EITHER SIDE OF ANY GAPS TO ENSURE YOU CAN STILL HAVE USE OF YOUR DOORS